


This drawing must be read in conjunction with all other contract documents including the project specifications, schedules and any instructions issued during the course of the contract. The Contractor must verify all dimensions on site and check the location of services before commencement of work. The Contractor is to verify the Superintendent of any discrepancies between the drawings or specifications. Drawings are not to be used for construction unless identified in the title block as 'for construction'. All drawings to be read at A1 unless otherwise stated. Drawings are intended for digital set-up and Dwg files will be issued upon request. Copyright Oxygen Pty Ltd

SCALE
1:150 (A1), 1:300 (A3)



NOTES

EXISTING SERVICES
THE CONTRACTOR MUST LOCATE AND MARK ALL UNDERGROUND SERVICES BEFORE COMMENCING WORK ON SITE.

TREE PLANTING
PREPARE TREE HOLES TO A MINIMUM SIZE OF THE DEPTH OF THE ROOTBALL x 1m WIDE AND BREAK THE SUBGRADE TO A MINIMUM DEPTH OF 200MM BELOW.

TAKE PARTICULAR CARE TO BREAK UP ANY GLAZING TO SIDES OF TREE HOLE.

FINISH THE ROOTBALL LEVEL WITH THE FINAL SURROUNDING SOIL LEVEL AND BACKFILL THE PLANTING HOLE WITH IMPORTED SANDY-LOAM TOPSOIL (80%-20% SANDY-LOAM) MIXED THOROUGHLY PRIOR TO PLACING WITH 20% ORGANIC COMPOST).

PROVIDE A 1m DIAMETER MULCHED WATERING BOWL TO THE BASE OF THE TREE.

STAKE TREES WITH 2 No. 2500x50x50 HARDWOOD STAKES AND TIE WITH 50mm HESSIAN TIES SECURELY STAPLED TO THE STAKES. ENSURE STAKES AND TIES REMAIN CLEAR OF BRANCHES, FOLIAGE AND ROOTBALL.

PLANTING BEDS
CULTIVATE EXISTING GROUND TO A MINIMUM DEPTH OF 300 MM AND PLACE 300MM IMPORTED SANDY-LOAM TOPSOIL (80%-20% SANDY-LOAM) MIXED THOROUGHLY PRIOR TO PLACING WITH 20% ORGANIC COMPOST).

PLACE PLANTS IN THE CENTRE OF THE PLANTING HOLE AND FINISH THE TOP OF THE ROOT BALL LEVEL WITH THE FINISHED SURFACE OF THE SURROUNDING SOIL.

APPLY TERRACOTTE FERTILISER TO MANUFACTURERS RATES AT TIME OF PLANTING AND AFTER PLANTING.

PLACE A 100MM MINIMUM DEPTH OF FINE GREEN WASTE MULCH, THOROUGHLY WATER PLANTS BEFORE AND IMMEDIATELY AFTER PLANTING, AND AS REQUIRED TO MAINTAIN HEALTH AND VIGOUR.

IRRIGATION
PROVIDE AN AUTOMATIC IN-LINE DRIP IRRIGATION SYSTEM TO ALL PLANTING BEDS AND TREES.

DRIP IRRIGATION SPECIFIED AS NETAFAIM TECHLINE 16 POLY TUBE 1.6Lph @ 0.5M SPACINGS.

FOR ALL TREE PLANTING INSTALL AT BASE OF TREE 4No 4Lph PC DRIP EMITTERS ON 13MM POLY LOOP (OR INLINE EQUIVALENT).

ALL POLY TUBING TO BE LAID ON SURFACE AND COVERED WITH MULCH.

PROVIDE BACKFLOW PREVENTION, AUTOMATIC CONTROLLER AND OTHER DEVICES AS REQUIRED.

LEGEND


- NEW
- EXTENT OF WORKS
- NEW TREE REFER TO DETAIL 01
- PLANTING REFER TO DETAIL 02

TREE SCHEDULE

Key	Botanic Name	Pot	Qty.
BI	Banksia integrifolia	45 Litre	5
LN	Lagerstroemia 'Natchez'	45 Litre	2
LZ	Lagerstroemia 'Zuni'	45 Litre	3
LC	Lagerstroemia 'Comanche'	45 Litre	6
PC	Pistacia chinensis	45 Litre	4


PLANT SCHEDULE

Key	Botanic Name	Spacing	Pot	Qty.
CB	Callistemon 'Brogo Overflow'	2 / m ²	14.0mm	91
CS	Callistemon sieberi	1 / m ²	14.0mm	35
CD	Correa 'Dusky Belts'	1 / m ²	14.0mm	41
GH	Grevillea 'Honeyeater Heaven'	1 / m ²	14.0mm	46
GL	Grevillea lanigera	2 / m ²	14.0mm	73
RO	Rhaphirolepis 'Oriental Rose'	2 / m ²	14.0mm	47



02 TYPICAL SHRUB PLANTING DETAIL

SCALE 1:10 @ A1



01 TYPICAL TREE IN MULCH DETAIL

SCALE 1:20 @ A1



oxygen

Oxygen Pty Ltd
98-100 Halifax Street
Adelaide SA 5000

T +61 (08) 7324 9600
design@oxygen.net.au
oxygen.net.au

CLIENT PEREGRINE CORPORATION ARCHITECTS ADS ARCHITECTS



PROJECT MIDVALE OTR drawing title LANDSCAPE PLAN

15.04.7.127

ISSUE DRAFT

B

ISSUE	DATE	ISSUE	DWN	CHK	APP
A	29.05.23	DRAFT	EH	JH	JH
B	05.07.23	DRAFT	EH	SD	JH